





B-FSB-H-1/3

The B key exchange box is designed to enable the sequential release of keys (maximum 5) by the insertion of one or more initial key(s). The need for this type of product usually arises when there are multiple access points to the hazardous area. The unit will generally be the link between the isolation locks and the access products. The product is supplied in an enclosure suitable for surface or panel mounting, and is available in different configurations of locks.

Operation


Castell Key Exchange Boxes are used in various applications to control multi-door access to hazardous areas.

B key exchange box, horizontal mount (1 key free - 2 keys trapped)

- 1 key free, 3 keys trapped
- 2 Insert and turn free key, then turn and release trapped keys in a sequence
 - 3 1 key is trapped, 3 keys released







- 1. While 1 key is free which is usually used in power isolation, 2 keys are trapped.
- 2. By inserting and turning the free key in the B key exchange box, you can sequentially release trapped keys. The released keys can be used in the access door locks to gain access to the hazardous area.
- 3. The inserted key stays trapped until all released keys are returned to their original position.

The B key exchange box is available in different combinations of free and trapped keys and also in a vertical mounting version.

B

Key Exchange Box User Manual - Original Language Version



Usage

B key exchange boxes should be used to allow a safe access to potential hazardous and dangerous areas with one or more access points.



The B key exchange box is not designed for security purposes, such as a safe or external access to a building.

No hazardous substances were used in the manufacture of this product. The product can be disposed of in standard waste.

Installation

The B key exchange box should normally be mounted on the static frame using suitable fasteners. Please refer to the drawing on page 4 for maximum and minimum mounting distance. The B key exchange boxes are available in horizontal and vertical mounting versions. Anti vibration pads should be used on machines that generate a high level of vibration



IMPORTANT:

The B key exchange box should be mounted using anti-tamper fasteners to prevent unauthorised removal.



The B key exchange box must be installed by a competent and qualified person who has read and understood these instructions. Please retain this document in your technical file.

Maintenance

Periodic visual checks should be carried out by the site manager/safety officer. Do not lubricate lock barrel with oil or grease, use CK Dry Powder Graphite if necessary.



In case of defects being detected please contact your nearest Castell Support Department for further actions. Please see Contact section for contact details.





Technical Data

	Minimum: -40°C [-40°F] ice free for Q & FS type			
Temperature rating	Maximum: 107°C [224,6°F] for Q type/140°C [284°F] for FS type or 288°C [550°F] upon request			
Type of mounting	ype of mounting Panel mount using suitable fasteners (please refer to drawing on page 4 for more detail			
NA/-:	Brass: 1 kg for 2 lock oprtions, add 0,5 kg per additional portion			
Weight	Stainless steel: 1 kg for 2 lock oprtions, add 0,5 kg per additional portion			
Material	Prial Brass or stainless steel			
MTTF Certification	Available on request			


Application

A typical application of the B key exchange box is machine guarding with one or more access points to the hazardous area.

The B key exchange box is used as a part of a safety system, which ensures a machine is shut down, before access to the hazardous area is allowed. The system involves a KS key switch for the electrical supply and typically more than one AIE access interlocks for full body access.

The removal of the isolation key from the key switch isolates the electrical supply to the machine. This key is taken to the B key exchange box to release the trapped keys. The released keys are used to gain access through the AIE door interlocks.

The machine cannot be restarted until all keys are returned to the key exchange box and the power isolation key is removed and replaced in the KS key switch.



EC-Declaration

We, the manufacturers, declare that the components, detailed herein and placed on the market, comply with all the essential health and safety requirements applying to them.

Empowered signatory:

Mr T.C. Whelan Managing Director








Drawing

Dimensions:

Note: For safe mounting, use security screws

B key exchange box, horizontal mount







Order Information

	Product Type		1	2		3		4		5
Part Number	В	-] - [] - [
					_		_			
Example	В	-	FS	В] - [Н		1	/	3
	6									
	А	Fr	ee Key Syr	mbol(s)						
	7									
	B1	En	d Key Syr	nbol(s)						

1	Lock portion type	FS ⁽¹⁾ / Q ⁽¹⁾
2	Material	B = Brass
3	Mounting	H = Horizontal V = Vertical
4	Number of Free Keys	please specify
5	Number of Trapepd Keys	please specify
6	Lock portion symbol(s) - Free Key(s), all to be advised separately	FS ⁽¹⁾ up to 3 characters / Q ⁽¹⁾ up to 6 characters
7	Lock portion symbol(s) - Trapped Key(s), all to be advised separately	FS ⁽¹⁾ up to 3 characters / Q ⁽¹⁾ up to 6 characters

(1) FS - Lock type Q - Lock type Up to 3 characters Up to 6 characters







Accessories

Special construction available upon enquiry

Product	Part number
Flip Cap	FLIP-S

Contact Information

Castell Safety International Ltd. The Castell Building 217 Kingsbury Road London, England NW9 9PQ

t: +44 (0) 20 8200 1200 f: +44 (0) 20 8905 9378 e: uksales@castell.com Castell Safety International Ltd. Oskar-Jäger-Strasse 137 50825 Köln Germany

t: +49 (0) 221 1694 794 f: +49 (0) 221 1694 795 e: vertrieb@castell.com

Castell Interlocks Inc. Suite 800 150 N Michigan Avenue, Chicago, Illinois 60601

t: +1.312.360.1516 f: +1.312.268.5174 e: ussales@castell.com Castell Safety China Building 1, No. 123, Lane 1165, Jindu Road, Minhang District, Shanghai 201108, China.

t: +86 21 61519023 f: +86 21 61519030 e: chinasales@castell.com

While every effort has been made to ensure the accuracy of the information provided, no liability can be taken for any errors or omission. Castell Safety International Limited reserves the right to alter specifications and introduce improvements without prior notice.